

BATA INDUSTRIALS FITTING GUIDE

The foundation for a good fitting work shoe is the perfect shoe shape or 'last'. Yet, our research shows us that feet are getting wider with each generation. With that in mind Bata Industrials uses a 'last' design with extra space around the front and instep for greater stability and comfort. We also provide an extensive range of length sizes.



INSTRUCTIONS FOR USE:

To determine your correct size,

Place your heel on the chart where indicated and measure to the end of the longest toe. If the toe is between numbers, choose the larger size.

For sizes 7/7½, 8/8½ & 10/10½.

Select 7½, 8½ & 10½, for a wider fitting or sizes 7,8 or 10 for a standard fitting.

This Men's fitting chart is to be used as a guide, the printed scale may distort due to the fold in the catalogue. Please check the length of your foot in mm and use the scale to determine your UK / Australian size.

| | | | | | | | | | | | | | | | |
|----------------------|------|------|------|------|-----|-----|------|--------|-----|-----|--------|--------|-----|-----|-----|
| Mondo Point | 217 | 225 | 232 | 240 | 247 | 255 | 262 | 270 | 277 | 285 | 292 | 300 | 307 | 317 | 322 |
| European Sizes | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 |
| UK/Australian Male | 2-2½ | 3-3½ | 4-4½ | 5-5½ | 6 | 6½ | 7-7½ | 8-8½ | 9 | 9½ | 10-10½ | 11-11½ | 12 | 13 | 14 |
| UK/Australian Female | 4-4½ | 5-5½ | 6-6½ | 7-7½ | 8 | 8½ | 9-9½ | 10-10½ | 11 | 11½ | 12-12½ | 13-13½ | 14 | 15 | 16 |
| US Female | 4-4½ | 5-5½ | 6-6½ | 7-7½ | 8 | 8½ | 9-9½ | 10-10½ | 11 | 11½ | 12-12½ | 13-13½ | 14 | 15 | 16 |
| US Male | 2 | 3 | 4 | 5 | 6 | 7 | 7½ | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |