



## XD-8818 (item 125.876) INSTRUCTION!


1. press down the rear round button then push out the button to take out the blade carrier



2. put snap off block hole on the first line of the blade, close the snap off line



3. when snap off the blade must put front side towards the desk or ground, it will be safe.



4. safty lock, when use the blade can lock the blade, blade will not shake

