


XD-123-1 (item no.3.339.192) INSTRUCTION!

1.safety cutter,push forward for using cutter,auto retractable



2.take off the button from the blade hole,then can replace the blade



