

## Installation Instructions

Please read Instructions BEFORE installing this Toner Cartridge. Follow the Toner Cartridge replacement information in your Printer Manual.

Turn off printer. Open cover. Remove empty cartridge.

Remove replacement cartridge from pouch. Rock new replacement cartridge several times to evenly distribute toner.

Where applicable slowly pull seal completely from new replacement cartridge and discard sealing tape.

Install cartridge completely along the guides. Close printer. Turn on Printer.

---

## STORAGE INFORMATION

- Do not expose to direct sunlight, dust, corrosive gases (ammonia, etc.) or salty air.
  - Temperature should be between 0°C and 35°C.
  - Do not store where temperature and humidity are high or subject to abrupt changes.
  - Do not use for at least one hour after moving it from a cool to warm environment.
  - The cartridge should always face up.
- 

## USER GUIDE

Dear customer,

Thank you for purchasing one of our products. You can be assured, you are receiving a high quality product, helping to protect our environment and assist in reducing your own printing costs. This guide should be used only in conjunction and in accordance with your printer's user manual.

## PRINTER SERVICE, PROBLEMS WITH PRINTED IMAGE, MAINTENANCE AND REPAIR

Should your device not function or you have problems with print quality, first consult your user manual and this guide, or call your dealer, who sold you the product, or maintenance company. In the first instance by carefully following these instructions and those in the manufacturers guide you will be able to resolve most of the common problems which occur in your device before having to contact service, or supply companies, saving you time and potential costs.

## RETURNING EMPTY CARTRIDGES

Do you want to dispose of your empty cartridges correctly and in accordance to the environment protection? Then simply return the toner cartridge to it's packaging. When doing this, use the inner parts of packaging to pack the toner cartridges safely for transport. Following this, contact your supplier/dealer to make arrangements for collection.

1. Turn off the device, Open the door of your device.(Printer/Fax/MFC device)
2. Remove the empty toner cartridge according to the instructions in your user manual.

3. Carefully clean the metal parts with a clean, dry cloth.
4. Pull out the toner cartridge from the protective bag. Never touch chip or drum surface if those are present on cartridge. Carefully move your new toner cartridge several times forward and backward. This agitates the toner within the cartridge housing.
5. If your cartridge has a seal remove it by slowly pulling it completely from the toner cartridge. Some toner cartridges may have drum covers protected by an additional seal. Remove this seal also. If your cartridge has an automatic seal or no seal at all please skip this step.
  - a. Remove the big red safety seal of your cassette.
6. Pay attention to insert the cartridge correctly as advised in the installation manual into the device. Hold it in the way that you are able to read the blue label, the toner tank is positioned towards you, and the drum/ drum cover is turned down.  
Close the cover and just turn on your device, it is now ready to function.