


Wall & magnetic support brackets usage guidelines

Wall Support Brackets


- 1 Position the support bracket on the desired wall.
- 2 Choose a suitable screw and roll plug for the chosen surface (not supplied). The screw head should be at least 10mm in diameter. Fasten tightly with a screwdriver until the bracket is secure. We also recommend using a washer to protect the bracket.
- 3 Slide the Skipper unit onto the bracket until it clicks into place.



Magnetic Support Brackets

- 1 Slide the Skipper unit onto the bracket until it clicks into place.
- 2 Position the support bracket on the desired magnetic surface.

To remove the Skipper unit from the bracket, pinch the spring clip while pulling the Skipper unit upwards.



Made in the United Kingdom

Web: www.skippertm.co.uk

Tel: +44 (0) 844 412 7757

Fax: +44 (0) 844 412 7758

Email: sales@skippertm.co.uk

Skipper™

The total safety management solution