

**i**

x1 1 min

[www.my-unilux.com](http://www.my-unilux.com)

**+**

Ⓐ x1

+

1AA1,5V(supplied)  
Average consumption: 0,20mA

22 cm



**1**

1 x AA/ LR6

**2**

1'

**3**

20'

After inserting the battery , the clock hands move to 12 c'clock position. After 20 minutes, the clock automatically sets itself at the right time . Do not move the clock during signal reception. If the clock fails to set, change the place of reception, preferably near window or outside. Battery should be removed and reinsert after 1 min to restart signal reception.

Une fois la pile intégrée à l'arrière de la pendule, celle ci se règle sur la position de 12H. Après 20 minutes, la pendule sera réglée automatiquement sur le bon fuseau horaire. Ne pas bouger la pendule pendant ce temps de réglage. Préférez un emplacement près d'une fenêtre pour améliorer la réception du signal.