


HOW TO MEASURE



- Using a tailor's measuring tape, accurately measure your FC and HC.

HC = Head Circumference

Measure above the eyebrows, just above the ears, and over the occipital bone.

FC = Face Circumference

Measure from the top of the head down to below the throat, passing in front of the ears.

- Once you have the measurements, cross-check them with the table below to determine the best-fitting helmet for you between Zenith X and Zenith X Max.

HELMET SIZE RANGE



ZENITH X




SIZE: Adjustable – from 52 to 63 cm



ZENITH X MAX



SIZE: Adjustable – from 60 to 66 cm



SIZE CHART

		HC Head Circumference (cm)								
		52	54	56	58	60	62	63	64	66
FC Face Circumference (cm)	58	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X	/	/
	62	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X	/	/
	66	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X/X MAX	ZENITH X/X MAX	ZENITH X/X MAX	X MAX	X MAX
	70	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X/X MAX	ZENITH X/X MAX	ZENITH X/X MAX	X MAX	X MAX
	74	ZENITH X	ZENITH X	ZENITH X	ZENITH X	ZENITH X/X MAX	ZENITH X/X MAX	ZENITH X/X MAX	X MAX	X MAX
	78	/	/	/	/	X MAX	X MAX	X MAX	X MAX	X MAX
	82	/	/	/	/	X MAX	X MAX	X MAX	X MAX	X MAX
	86	/	/	/	/	X MAX	X MAX	X MAX	X MAX	X MAX
	87	/	/	/	/	X MAX	X MAX	X MAX	X MAX	X MAX

The result of the measurement comparison provides a guideline for selecting the most suitable helmet model.

Watch the video to explore the wide size range of the ZENITH X collection.

