

# TECHNICAL PRODUCT DATA SHEET

MAP0601502 - MAGNETIC DRY ERASE BOARD" WORLD MAP"



*MAGNETIC DRY ERASE BOARD" WORLD MAP" with ALUMINIUM FRAME.*

*Magnetic Dry Erase surface for use with dry wipe markers. Pen tray, 3 magnets (assorted colors) and wall fastening kit included*

**Brand:** **Bi-Office**

**Country of Origin:** Portugal

**Dimensions (cm):** 137,5X85,5 cm

**Product weight:** 5240 grams

**Packaging Unit:** 1 pc

**Packaging (carton) size:** 143X102X2,5 cm

**Packaging weight:** 7140 grams

**Product colours available:** N/A


**Material Safety Data Sheet required?** NO

**Product materials , as follows:**

# TECHNICAL PRODUCT DATA SHEET

MAP0601502 - MAGNETIC DRY ERASE BOARD" WORLD MAP"


**a) Surface:** Board is composed by a substrate (backboard) with a magnetic printed and dryerase surface.



**b) Frame:** Anodized Aluminium frame - "MAYA" model:



**c) Plastic corner:**



**d) Pen tray:** 30 cm length plastic tray, "MAYA" model:



**e) Accessories:** Polybag with 4 screws, 4 plug stoppers, Instructions label:



# TECHNICAL PRODUCT DATA SHEET

## MAP0601502 - MAGNETIC DRY ERASE BOARD" WORLD MAP"

### f) Surface: Care & Maintenance Instructions - Important steps to prolong the life of your dry-wipe board

Important steps to prolong the life of your Magnetic/Dry erase Board



1-For the initial cleaning, wipe your board with a clean cloth moistened by Bi-office spray cleanser or use our Bi-office tissues cleaners. Rinse with clear water. Wipe dry with a clean cloth. This step is simple but very important.



2-Regular cleaning should be done with a felt eraser. Wait until the ink is completely dry on the board. Wipe the board in a circular slow motion to loosen marker residue.. **THIS STEP IS VERY IMPORTANT.** If it still has some residue left draw over the lines with a dry erase marker. If the area is large, spray Bi-office cleaner on the stain and wipe clean.



3-If your board is used daily, the cleaning should be performed at least twice per week. More thorough cleaning may be required if writing is left on the board for more than 2 days.



4-Using only dry erase markers. **NEVER** using ballpoint pens and sharp objects as this will cause permanent damage. **NEVER** use an abrasive cleaner or glass cleaner on your dry erase board. This will remove the finish and impair the erasability of your board. Water is not an effective cleaner because most dry erase markers are water resistant.



Accidentally used a permanent marker on your board? Draw over the lines with an dry erase marker, then erase as usual.

5-Wash erasers with warm soap and water. Let the eraser dry completely before fluffing up the nap. Replace eraser when nap is worn.