




TAKTIK-MESH TS16 R19T ACTIV1



ASSEMBLY AND ADJUSTMENT INSTRUCTIONS

Before beginning the assembly, please check that all parts are enclosed.

PART LIST



- | | |
|--|---|
| <input type="checkbox"/> 1 back | <input type="checkbox"/> 4 screws M6x35 |
| <input type="checkbox"/> 1 seat with seat base | <input type="checkbox"/> 2 screws M6x30 |
| <input type="checkbox"/> 1 base | <input type="checkbox"/> 4 bushes |
| <input type="checkbox"/> 1 gas lift | <input type="checkbox"/> 6 pads |
| <input type="checkbox"/> 1 gas lift cover | <input type="checkbox"/> 2 arms |
| <input type="checkbox"/> 5 castors | <input type="checkbox"/> 1 allen key |

ASSEMBLY

1. Insert castors into base.
2. Pull gas lift cover over the gas lift.
3. Insert the gas lift into base.
4. Fit arms to seat with screws M6x30 and screws M6x35 with bushes.
5. Firmly locate the tapered end of the gas lift into locating hole in the seat.
6. Insert the back slider in the guide.

ADJUSTMENT

- The Seat height adjustment - lever **C**.
Gas lift allows the adjustment of the seat height.
- The seat and back tilt adjustment - lever **C**.
By pushing lever **C** forward (2) and giving pressure to the back - allows the seat and back free floating.
By pulling lever **C** backwards (3) - the seat and back can be locked in desired position.
- Backrest height adjustment:
The backrest returns to the lowest position, once the highest position is passed. In order to adjust the backrest to your desired position first slide the backrest fully up and let itself to slide down, then gradually move up the backrest to the required position.
- The arm height adjustment - **R**

MAINTENANCE

- Inspection** Inspect chair at least every six months to make sure all knobs, bolts and screws are tight.
- Vinyl upholstery** Wipe with damp cloth, moistened in a mild detergent solution. For unusual stains use commercial vinyl cleaner, following manufacturer's instructions.
- Fabric upholstery** Whisk or vacuum regularly. For unusual stains use commercial nylon cleaner, following manufacturer's instructions.
- Other surfaces** Wipe with a soft cloth, moistened in a mild detergent solution. Dry and buff lightly with a dry cloth.
- Attention**
Exchange and installation of gas-lifts should only be carried out by trained specialists.