

Technical specs

VISORHOLDER - VISOR-HOLDER (*VISHONO*)

Name:

FACESHIELD HOLDER FOR SAFETY HELMET QUARTZ / ZIRCON / BASEBALL DIAMOND

Size:

Single

Colour:

Black

**Description :**

Faceshield holder suitable for QUARTZ, ZIRCON and BASEBALL DIAMOND safety helmets. To combine with VISORPC, VISORG and VISOR-TORIC visors, universal fixing.

Materials:

ABS

175 gr

Instructions for use:

This faceshield holder is designed to fix faceshields (polycarbonate or gauze) on safety helmets. Before use, inspect the faceshield holder carefully, and change it if damaged.

Assembly of visor holder on the helmet:

To mount (by clipping) adapters on the each side of the helmet in the notches provide for this purpose. To insert the two sliding parts of the visor holder in these adapters.

Assembly of the visors on the visor holder:

Slide the notches of the visor into the visor holder fasteners. Turn the fasteners 90° to hold the visor in place. Remove the protective film before initial use.

Limits to use:

Only use for the purpose described in the above instructions for use. The materials used in these visors do not contain substances known as being carcinogenic or toxic. However, it is possible that some sensitive people may develop allergic reactions. In this case, stop all use and seek medical advice.

Instructions for storage:

Keep in its original packing away from light and humidity in a cool, dry place.

Instructions for cleaning / maintenance:

They may be cleaned and disinfected with a soft cloth and soap in warm water. Do not use solvents or abrasive products. Used in normal circumstances, these visors offer adequate protection for 6 months or more.

Performances :

Comply with requirements of the European Directive 89/686, special for ergonomics, harmlessness, comfort, airing and flexibility and with the requirements of the European standards according to the visor assembled above:

- 3BT EN166:2001 with VISOR-PC
- F EN1731:2006 with VISOR-G
- 389AT EN166:2001 with VISOR-TORIC