

# Technical specs

## M1100VC - M1100V

### Name:

BOX OF 10 MOULDED DISPOSABLE HALF-MASKS FFP1 WITH VALVE

### Colour:

White



CE 0194

### Description :

Non woven synthetic fibre facial filtering part FFP1. Husk format, noze bar of adjustment, reinforcement edge foams under nose bar, with valve. Box of 10.

### Materials:

Mask: non-woven synthetic fibre.

Straps : Rubber

### Instructions for use:

This mask is classified in accordance with its filtering capacity and maximum total inward leakage. FFP1 marking: Protective mask against solid and liquid particles without specific toxicity. Can be used for concentrations up to 4 X of the Average Exposure Value (AEV) Filtering capacity of the filter: 80% - Nominal Protection Factor (NPF) : 4.5.

Do not use for more than 8 hours and throw away after each use. Only take the mask out of its packaging just before you are going to use it. Only use when the concentration of contaminating agents does not pose an immediate risk to life or to health, and only in observance of the applicable health and safety standards. Before you use the mask, check that it is undamaged, that its expiry date has not been reached (see the box) and that the protection class FFP1 is appropriate for the product used and its concentration.

### Limits to use:

The user must have adequate training in the wearing of the mask and must have read the instructions before using it. Use the mask in well-ventilated areas, where there is no lack of oxygen (> 20%) and where there is no explosive atmosphere. The mask must be positioned correctly in order to provide the expected level of protection. Do not use if facial hair (beard, sideburns) prevent the mask from being fully sealed, and leakage is detected. Leave the area immediately if you experience breathing problems and/or dizziness or faintness. Do not make any modifications to the mask, and discard it if there is any damage to it. Failure to observe these instructions for use may have adverse effects on the health of the user and expose him to serious or even life-threatening risks. This dust mask shall not be used for more than one shift.

Do not use other than for the scope of use defined in the above instructions for use. Contact with the skin may cause allergic reactions in people with sensitive skin. In this event, leave the area of risk, remove the mask and seek medical advice.

### Instructions for storage:

Store in a cool dark place, in its original packaging.

### Instructions for cleaning / maintenance:

This mask must only be used once (no maintenance).

### Performances :

This mask complies with the European directive 89/686, notably regarding ergonomics, innocuousness, comfort, ventilation and flexibility, and with EN149:2001 standard (nominal protective factor: 4 X of the Average Exposure Value (AEV) for particles without toxicity).